DREMEL® ROTARY TOOL & ATTACHMENT COMPATIBILITY CHART

● COMPATIBLE
✕ INCOMPATIBLE
NA NOT ADVISED

		ATTACHMENTS															
		WORKSTATION (220 / 220-01)	FLEX SHAFT (225 / 225-01)	ROUTER TABLE (231)	PLUNGE ROUTER (335 /335-01)	RIGHT ANGLE ATTACHMENT (575)	MULTI-PURPOSE CUTTING KIT (565)	GROUT REMOVAL KIT (568)	MINI-SAW (670 / 670-01)	CIRCLE CUTTER & STRAIGHT EDGE GUIDE (678 / 678-01)	SHAPING PLATFORM (A576)	DETAILER'S GRIP (A577)	CHAIN SAW SHARPENER (A679-02)	LAWN MOWER & GARDEN TOOL SHARPENER (675)	MULTI-VISE (2500 / 2500-01)	DUST BLOWER (490)	SHIELD (A550)
CORDED	4300	●	●	Use with collet & collet nut	Use with collet & collet nut	●	Use with collet & collet nut	Use with collet & collet nut	●	Use with collet & collet nut	Use with collet & collet nut	●	Use with collet & collet nut	Use with collet & collet nut	●	Use with collet	●
CORDED	4200	●	ADAPTER REQUIRED	●	●	ADAPTER REQUIRED	●	●	ADAPTER REQUIRED	●	●	●	●	●	●	✕	●
CORDED	4000	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
CORDED	3000	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
CORDED	200	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
CORDED	100	●	●	●	●	●	●	✕	●	●	●	●	●	●	●	●	●
CORDED	STYLO+ (2050)	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	●	✕
CORDLESS	8220	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●	●
CORDLESS	8100	●	●	✕	✕	●	●	●	NA	●	●	●	●	●	●	●	●
CORDLESS	MICRO (8050)	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	●	✕
CORDLESS	7700	✕	✕	✕	✕	✕	✕	✕	✕	✕	●	●	●	●	✕	●	●
CORDLESS	7300	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	●	✕
CORDLESS	7000	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	✕	●	✕